

Quick Reference Guide

USER CAUTION AND SAFETY



Avoid exposure to any direct or reflected ultraviolet rays. Germicidal ultraviolet rays are harmful to the skin and eyes with direct exposure. **Remove the unit from service should any blue/violet light emit from the system.** Always use this system in a dry area and is plugged into a grounded electrical outlet.

System Setup and Installation

- Keep the case lid closed during this setup
- Locate the UV-C system on a stable surface
- Make sure power switch on the rear of the unit is in the **OFF** position
- Plug power cord into a 110 VAC grounded electrical outlet
- Plug the power cord into the rear of the unit
- The unit is now ready for use



Rear Power Switch and Plug
O – OFF I – ON



Grounded AC Outlet

System Operation

1. The UV-C cleaning cycle consists of 2 separate one-minute cycles and a 1-minute system cleaning cycle.
2. Power **ON** the unit using the rear power switch. The power switch will illuminate.
3. Open the case lid by releasing the two case front latches.
4. Insert items on the screen stage to be cleaned. *Space out the items and do not stack or overfill.*
5. Close and latch the case lid and the unit will start the first 1-minute decontamination cycle. The GREEN indicator on the case lid will illuminate during the cleaning cycle.
6. When the GREEN indicator turns off open the lid and flip over the items on the screen stage.
7. Close and latch the unit and the second cleaning cycle will start.
8. When the second cycle is completed (green indicator off) items can be removed and are ready for use.
9. Close the case lid and a 1 min cleaning cycle will start to clean the screen stage for the next user.



Note that when the unit lid is opened and closed the 1-minute cleaning cycle will always restart.

This is normal operation and assures a thorough cleaning process.